



# Landscape Fullview Series

LFV2-1000/400 • LFV2-1500/400 • LFV2-2000/400  
LFV2-2500/400 • LFV2-3000/400



**INSTALLATION/OWNERS MANUAL**  
RATED FOR 240V 50HZ INSTALLATIONS

SERIAL NUMBER: \_\_\_\_\_

**MODERN  FLAMES**

**LANDSCAPE FULLVIEW SERIES  
LFV2-1000/400 • LFV2-1500/400 • LFV2-2000/400  
LFV2-2500/400 • LFV2-3000/400  
SAFETY INFORMATION AND OPERATIONS MANUAL**



Read these instructions completely before beginning installation. Failure to follow them could cause a heater malfunction resulting in serious injury and/or property damage.

**WARNING:** All electric heaters have hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are or are stored.

This fireplace meets the construction and safety standards of H.U.D. for application in manufactured homes when installed according to these instructions.

**INSTALLER:** Leave this manual with the appliance.  
**CONSUMER:** Retain this manual for future reference.

# USER INSTRUCTIONS

## TABLE OF CONTENTS

Important Instructions.....	3	Operation .....	9
Power Data .....	4	Service Parts.....	10
Product Guide .....	4	Troubleshooting .....	12
Box Contents.....	5	Frequently Asked Questions .....	13
Locating Fireplace.....	5	Cleaning and Maintenance Instructions .....	14
Installation .....	5	Wiring Diagram .....	14

## IMPORTANT INSTRUCTIONS

When using electrical heaters, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

**WARNING: Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information, consult a qualified installer.**

**CAUTION: Do not expose the heater to the elements (such as rain, etc).**

**Do not place clothing or other flammable material on or near firebox. Never place any objects on the fireplace.**

**Carefully supervise young children when they are in the room with fireplace.**

**Fireplace becomes very hot when running. Keep children and adults away from hot surfaces to avoid burns or clothing ignition. Fireplace will remain hot for a time after shutdown. Allow surfaces to cool before touching.**



**CAUTION: In order to avoid overheating, do not cover the heater.**


1. Read all instructions before installing or using this heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9m) from the front of the heater and keep them away from the sides and rear.
3. Extreme caution is necessary when any heater is used by or near children or disabled people and whenever the heater is left operating and unattended.
4. Do not operate any heater after it malfunctions, has been dropped, or damaged in any manner. Disconnect power at service panel and have heater inspected by an authorized technician or a reputable electrician before using.
5. Do not use outdoors.
6. To disconnect heater, turn controls to off and turn off power to heater circuit at main disconnect panel.
7. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
8. To prevent a possible fire, do not block air intakes or exhaust in any manner.
9. A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable vapors or liquids are used or stored.
10. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
11. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
12. SAVE THESE INSTRUCTIONS

# USER INSTRUCTIONS

## POWER DATA

	LFV2-1000/400	LFV2-1500/400	LFV2-2000/400	LFV2-2500/400	LFV2-3000/400
Volts/HZ Amps	AC 240V/50HZ 9.25 Amps	AC 240V/50HZ 9.25 Amps	AC 240V/50HZ 9.25Amps	AC 240V/50HZ 9.25Amps	AC 240V/50HZ 9.25 Amps
Heater	AC 240V/50HZ 1.1kW/2.2kW	AC 240V/50HZ 1.1kW/2.2kW	AC 240V/50HZ 1.1kW/2.2kW	AC 240V/50HZ 1.1kW/2.2kW	AC 240V/50HZ 1.1kW/2.2kW
Lamps	LED 12V	LED 12V	LED 12V	LED 12V	LED 12V
Rotor motor	AC 240V/50HZ 4W CCW 15/18 r/ min	AC 240V/50HZ 4W CCW 15/18 r/ min	AC 240V/50HZ 4W CCW 15/18 r/ min	AC 240V/50HZ 4W CCW 15/18 r/ min	AC 240V/50HZ 4W CCW 15/18 r/ min
Shipping Size	1473mm x 661mm x 356mm	1981mm x 661mm x 356mm	2489mm x 661mm x 356mm	2997mm x 661mm x 356mm	3505mm x 661mm x 356mm


## PRODUCT GUIDE



Model	Viewing Area	Firebox Dimensions	Framing Dimensions
LFV2-1000/400	1016mm W x 381mm H	1391mm W x 572mm H x 292mm D	1416mm W x 585mm H x 305mm D
LFV2-1500/400	1524mm W x 381mm H	1899mm W x 572mm H x 292mm D	1924mm W x 585mm H x 305mm D
LFV2-2000/400	2032mm W x 381mm H	2407mm W x 572mm H x 292mm D	2432mm W x 585mm H x 305mm D
LFV2-2500/400	2540mm W x 381mm H	2915mm W x 572mm H x 292mm D	2940mm W x 585mm H x 305mm D
LFV2-3000/400	3048mm W x 381mm H	3423mm W x 572mm H x 292mm D	3448mm W x 585mm H x 305mm D

# INSTALLATION

## BOX CONTENTS



## LOCATING FIREPLACE

**CAUTION:** Do not locate in a moist room such as a bathroom or laundry room.

**CAUTION:** Wear gloves and safety glasses for protection during installation and maintenance.

## INSTALLATION

**WARNING:** If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

### WARNING - RISK OF FIRE!

To prevent a possible fire, do not block air intake or exhaust in any manner. Do not use on soft surfaces where openings may become blocked.

### WARNING - RISK OF FIRE!

Do not blow or place insulation against the firebox.

To reduce the risk of fire do not store or use gasoline or other flammable vapors in the vicinity of this or any other heater.

**CAUTION:** Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 1 meter from the front of the heater and keep them away from the sides and rear.

### Installing fireplace

Select a suitable location that is not susceptible to moisture and is a safe distance from drapes, furniture and high traffic areas. A qualified electrician should add a flexible 10 amp 220-240 volt circuit per local building codes. This appliance does not have a power supply cord and must be installed to a proper circuit breaker. This appliance should not be installed directly below or in front of an existing wall socket.



*Note: Follow all national and local electrical codes.*

# INSTALLATION

Model	H	W	D
LFV2-1000/400	585mm	1416mm	305mm
LFV2-1500/400	585mm	1924mm	305mm
LFV2-2000/400	585mm	2432mm	305mm
LFV2-2500/400	585mm	2940mm	305mm
LFV2-3000/400	585mm	3448mm	305mm

1. Prepare the framed opening according to the chart above. Provide a dedicated flexible 10 amp 220-240 volt circuit for hard wire installation.


2. Install L Metal Nailing Flanges.




To be performed by a qualified electrician according to local building codes.

The means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

3. Connect hard wire to the terminal block according to the diagram below. Choose any connector type according to local building code.





Terminal block



# INSTALLATION

4. Install the fire unit in the framed opening with a minimum 1 ¼ drywall screws to secure the unit.



5. Mask the exposed fire unit during the drywall process. Install drywall to the drywall stops on the perimeter of the fire insert. For more information on the drywall stops see the Product Guide on page 4. Decorate as desired.
6. After installation, user may elect to use the L Metal Deco Trim. To install, use a small amount of construction adhesive and secure to the drywall face.


# INSTALLATION

## Installing remote touch control

1. Locate and remove the electrical access door on the rear right side of the fire unit.
2. Locate the remote touch control directly inside the access panel. Pull the touch control through the access panel and replace the access door. Locate the touch control anywhere within cable length. **DO NOT INCREASE LENGTH OF WIRES CONNECTING TOUCH CONTROL TO UNIT. DO NOT STAPLE OR PINCH WIRE**
3. Remove glass face (attached with magnets) from touch assembly. Cut out drywall to match orange bracket. Turn the 2 screws visible in the face to secure the bracket to the wall. Replace the glass face.


It is highly recommended the remote touch control be installed and mounted near the fireplace for best installation and operation of fireplace.

If you decide not to install the touch control unit in the wall, **IT IS IMPORTANT YOU LEAVE THIS WIRED TO THE UNIT AND STORED INSIDE THE ELECTRICAL ACCESS WHERE IT ORIGINALLY COMES STORED.** This is important for servicing the fireplace.



**ELECTRICAL ACCESS DOOR**

Touch control glass face




## Installing a fire feature (Canyon Juniper Log set, Crystal Glass Coal set)

1. Remove the inner glass panel by first removing the 2 screws in the finger pull tabs (finger pull tabs are located on the top of the glass panel.) Tilt the glass face down about 45 degrees and remove the glass. Store the glass panel upright (not on it's face) in a safe place.

**CAUTION:** There are locator pins on the bottom of the glass panel. Lift gently to avoid damaging the pins and unit face.

Finger pull tabs




2. Follow the instructions included with the fire feature.



# OPERATION


## OPERATION

The unit is hardwired and has no main switch. (Caution: If servicing this unit, turn off power at the main circuit breaker.) A remote wall control switch is included, refer to installation instructions to relocate the remote wall control switch to a wall location.




**NOTE:** If the touch control is not responding to touch upon installation, ensure the glass face is mounted correctly on the fireplace. Turn off the power to the fireplace from the main power switch on the bottom of the fireplace. Let sit for 60 seconds, turn the power back on and wait another 30 seconds for complete reset of the touch control.

When all indicator lights are off, touching any button will only show the status. Once the indicator lights are on you can begin operation. Touch the Power button to turn the machine on. This will be indicated by 1 orange LED light turning off and machine operating. Touch the Power button again to turn off the machine. The Heat button can be pressed multiple times and will turn on low, high and off in that order. The Dimmer/Color button turns on high, medium, low and off in that order. Long-press the Dimmer/Color button to toggle the flame color from orange to blue.




I.R./R.F. REMOTE


### Power indicator lights for wall switch as well as lower right corner of the main unit



When the switch turns on, this orange pilot lamp turns on. It shows the fire is energized.










The status light above shows that the power is on and the heater is on low









The status light above shows that the power is on and the heater is on high

The On/Off button toggles the unit on or off. The Color button toggles the flame image from orange to blue. The Dimmer button will lower the brightness of the flame and turn the flame off at the lowest setting. The Bright button will make the fire image brighter. Press the Heat down arrow for low heat (3750 BTU). Press the Heat up arrow for high heat (7500 BTU). Press either of these buttons twice to turn the heat off.

**Pairing remote:** To pair remote, turn off the fire unit at the main power switch for 30 seconds. Hold the On/Off button on the remote while flipping the main power switch back to on. When the fire unit powers up, the remote will be paired. **NOTE:** This is only for RF models and may need to be performed more than once. Sometimes tapping ON/OFF button rather than holding button will work best. For IR models aim at right side of FIREPLACE.

<b>LANDSCAPE SERVICE PARTS</b>		
ITEM	PHOTO	COMMENTS
MFPCB3		PRINTED CIRCUIT BOARD CONTROLS LOW VOLTAGE AND HIGH VOLTAGE FUNCTIONS AND TRANSFORMER
LFV2-TC3		LCD TOUCH CONTROL
HF24015-R		HEATER FAN 240V RIGHT HAND
HF24015-L		HEATER FAN 240V LEFT HAND
HC240V1.1kW		HEATER 240V 1100 WATTS
MFSM240		SPINDLE MOTOR 240V 50-60 HZ
LFV-PIB		LED POWER INDICATOR BOARD
MFR3-6 or MFR3-6-IR		6 BUTTON RF REMOTE CONTROL or 6 BUTTON IR REMOTE CONTROL

# MAINTENANCE

MFPLS240 LED		LED LIGHT STRIP LS2 40
MFPLS260 LED		LED LIGHT STRIP LS2 60
MFPLS280 LED		LED LIGHT STRIP LS2 80
MFPLS2100 LED		LED LIGHT STRIP LS2 100
MFPLS2120 LED		LED LIGHT STRIP LS2 120
MFPLS240 LED		EMBER BED LED LIGHT STRIP LS2 40
MFPLS260 LED		EMBER BED LED LIGHT STRIP LS2 60
MFPLS280 LED		EMBER BED LED LIGHT STRIP LS2 80
MFPLS2100 LED		EMBER BED LED LIGHT STRIP LS2 100
MFPLS2120 LED		EMBER BED LED LIGHT STRIP LS2 120
LFVGF40		INNER GLASS FACE
LFVGF60		
LFVGF80		
LFVGF100		
LFVGF120		
LFVDT40		ONE PIECE DECO TRIM
LFVDT60		
LFVDT80		
LFVDT100		
LFVDT120		
LFVIM40		INNER MODULE INCLUDING GLASS FACE, POLY SCREEN AND INDIVIDUAL BOX
LFVIM60		
LFVIM80		
LFVIM100		
LFVIM120		
<b>LFV2-WTC-GLASS-SINGLE</b>		WALL MOUNTED TOUCH CONTROL GLASS FACE ONLY

## TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Nothing comes on (touch screen, etc.)	A. Breaker tripped or circuit has no power	A. Reset breaker, test circuit for power
	B. Internal component is frozen and needs to be reset	B. Turn power off at the main breaker for 60 seconds. Turn power back on.
	C. Defective component	C. Need to replace motherboard, transformer or touch control
Touch Screen Comes on - then nothing	A. Not operating touch control properly with finger	A. Press flat part of finger firmly on the touch screen and apply moderate pressure
	B. Loose connection on motherboard	B. Check functions with remote control. if functional, check connections on motherboard
	C. Touch control harness damaged	C. Replace harness
Fireplace turns off and will not turn back on	A. Fireplace has overheated and safety disc has snapped or circuit breaker has tripped	A. Turn the main breaker to the "off" position for 60 seconds. Next flip the breaker back into the "on" position.
Can operate fireplace functions with touch controls but not remote control	A. Low Batteries	A. Replace batteries in remote control with - CR2025
	B. Remote not paired properly	B. To pair remote, turn off the fire unit at the main power switch for 30 seconds. Hold the On/Off button on the remote while flipping the main power switch back to on. When the fire unit powers up, the remote will be paired.
	C. Remote control defective	C. Replace remote control
	D. Remote Sensor is defective	D. Replace remote sensor inside fireplace if applicable
Heater does not provide heat when on	A. Wiring is loose	A. Disconnect unit from power source and inspect for loose connections
	B. Thermal snap disc has been tripped	B. Turn the main breaker to the "off" position for 60 seconds. Next flip the breaker back into the "on" position.
	C. Heater core is defective	C. Replace Heater Core

# MAINTENANCE

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Flame is not visible when unit is turned on	A. Wiring is loose	A. Disconnect unit from power source and inspect for loose connections
	B. LEDs are defective	B. Replace LEDs
Fireplace lights up but there is no flame image or frozen flame	A. Wiring for motor is loose	A. Disconnect unit from power source and inspect for loose connections from motor
	B. Motor is defective	B. Replace motor
Fireplace is squeaking when flame image is on	A. Fireplace spindle/ rod is contacting to metal	A. Apply lithium grease or any standard grease to contacts with rod and metal
	B. Motor is defective	B. Replace motor

## FREQUENTLY ASKED QUESTIONS

Q. How do you change the fire unit to Fahrenheit/Celsius?

A. Long press on the up and down arrows on the fire unit to toggle between Fahrenheit and Celsius.

Q. What distance can the remote be used from the fireplace?

A. Optimal distance for the remote control is within 6 meters.

Q. Can you turn on the fireplace via the touch screen and off via the remote (or vice versa)?

A. Yes.

Q. Can the fireplace be installed outside?

A. No. Please review the entire safety chapter before installing this fireplace.

Q. Does the fireplace need to be on a dedicated circuit?

A. Yes.

Q. What thickness of sheetrock should be used for the recessed installation? A. 12mm or 16mm.

Q. How often do the batteries in the remote need to be replaced? A. Annually, possibly more with heavy use.

Q. Is there a remote receiver in the fireplace that requires batteries?


A. No, only the actual remote requires batteries. The rest of the fireplace runs entirely off of the main power supply.

## CLEANING AND MAINTENANCE INSTRUCTIONS

There is very little maintenance involved with your electric fireplace. Please follow the few points below:

- On a semi-annual basis unplug the machine from it's power source, wait for the heating element to cool and dust the fire unit with a dry cloth. Be careful not to brush any wires that may be exposed as you do this.
- To clean the glass face of the fireplace simply use your desired glass cleaner with paper towels.
- To clean the air inlets/outlets, wipe with a soft cloth or the nozzle of a vacuum cleaner
- Dust can easily build up around the heater area inside the fire unit, on the left and right sides. Take particular care to clean this area on a regular basis to prevent buildup.
- If long time no use, please unplug the fireplace and stock it at indoor dry position.

## WIRING DIAGRAM



---

---

---

---

---

---

---

---

**DO NOT RETURN TO STORE!**



**CALL US FIRST**

For immediate help with installation, product information or if your product arrives damaged, please call our toll free number at:

**1300 361 557**

(Monday - Friday, 9:00AM - 4:00PM, AEST)

Or email us at:


**[info@modernflames.com](mailto:info@modernflames.com)**

**OUR STAFF IS READY TO PROVIDE ASSISTANCE**

© 2019

MODERN  FLAMES

[www.modernflames.com](http://www.modernflames.com)  
Please dispose of properly.



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To re-turn your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

The batteries contain materials, which are hazardous to the environment; they must be removed from the appliance before it is scrapped and that they are disposed of safely.